



Standox Fibre Body Filler For Zinc U1010 is a fibreglass reinforced body filler. It adheres to sheet metal and to glass-reinforced plastic, as well as cured old paintwork. It is easy to apply and to sand.

- · Coarse fibreglass-reinforced polyester stopper.
- · Can be used to repair small rust holes.
- Suitable for steel sheet, UP-glass fibre (unsaturated polyester), glass fibre reinforced plastic, and aluminium.
- · Suitable for galvanised substrates.




Product preparation - application STANDARD



It is strongly recommended to use appropriate personal protection equipment during application to avoid respiratory, skin and eye irritation.







Galvanised steel or soft aluminium sanded and cleaned.

Glass fibre reinforced polyester substrates, free of release agents, sanded and cleaned.



Stopper	Hardener
Weight	Weight
100	2
U1010	BPO BLUE BPO RED HARD PASTE U1120 B HARD PASTE U1120 R



Pot life at 20°C: 4 min - 5 min

Apply smooth film immediately after mixing, avoiding air entrapment.







Guideline for short wave IR equipment Half power: 2 - 3 min



P60 - P80



2K Polyester Stopper

VOC compliant

2004/42/IIB(b)(250) 150: The EU limit value for this product (product category: IIB(b)) in ready to use form is maximum 250 g/l of VOC. The VOC content of this product in ready to use form is maximum 150 g/l.

Products

Standox Fibre Body Filler for Zinc U1010

BPO Hardener Paste Blue BPO Hardener Paste Red STANDOX HARDENER PASTE, BLUE STANDOX HARDENER PASTE, RED

Product mix

The choice of hardener and Thinner should be made according to application temperature and size of repair.

U1120 red / BPO Red Standard hardener paste for dedicated Standox Polyester Stoppers.

U1120 blue / BPO Recommended for dedicated Standox Polyester Stoppers. Mainly used at

higher application temperature.

Clean after use with a suitable solventbased cleaning thinner.

Remarks

- · Do not add more hardener than recommended to avoid bleeding and spot marking.
- Do not apply over 1K primer, etch primer or not well cured paintwork.
- · Do not wet sand.
- Reaction temperature should be at least +5°C.
- · Application : Holes

Substrate: Non supporting parts of the vehicle Small holes up to approx. 1cm in diameter

Fill in and cover area with Standox Fibre Body Filler for Zinc U1010.

Larger damage

- Use glassfibre mat (1-2 mm grid).
- This should extend 5-10 cm beyond the edges of the repair.
- Fill area for repair work with Standox Fibre Body Filler for Zinc U1010. Then press glass fibre mat into freshly applied Standox Fibre Body Filler for Zinc U1010.
- After 10-20 min at 20°C apply Standox Fibre Body Filler for Zinc U1010 to the glassfibre mat and spread over the edges.





Consult Safety Data Sheet prior to use. Observe the precautionary notices displayed on the container.

All other products referred to in the refinish build up are from our Standox product range. System properties will not be valid when the related material is used in combination with any other materials or additives which are not part of our Standox product range, unless explicitly indicated otherwise.

For professional use only! The information provided in this documentation has been carefully selected and arranged by us. It is based upon our best knowledge on the subject at the date of issuance. The Information is given for information purposes only. We are not liable for its correctness, accuracy and completeness. It is up to the user to check the information with regard to up-to-dateness and suitability for his intended purpose. The intellectual property in this Information, including patents, trademarks and copyrights, is protected. All rights reserved. The relevant Material Safety Data Sheet and Warnings displayed on the product label need to be observed. We may modify and/ or discontinue operation of all or portions of this Information at any time in our sole discretion, without notice and assume no responsibility to update the Information. All rules set forth in this clause shall apply accordingly for any future changes and amendments.